

## **POCKETFINDER VEHICLE INSTALLATION WARNINGS**

LBT RECOMMENDS THAT CUSTOMERS USE A PROFESSIONAL AUTOMOTIVE TECHNICIAN TO INSTALL THEIR POCKETFINDER VEHICLE DEVICES.

LBT RECOMMENDS THAT CUSTOMERS INSTALL THEIR POCKETFINDER VEHICLE UNITS IN THE TRUNK OF THEIR VEHICLE OR UNDER THE DASHBOARD TO ENSURE MAXIMUM SAFETY.

ADDITIONAL PRECAUTIONS:

- 1) Engine must be turned off and cool prior to installing the device.
- 2) Do not place wires anywhere they may overheat.
- 3) Do not place wires anywhere that may cause them to be cut.
- 4) If the device is mounted on the inside of your engine compartment, make sure it does not overheat.
- 5) If the device is mounted inside of your engine compartment, check the device often to ensure it is still properly attached to your vehicle. Devices can become dislodged.
- 6) Do not affix the device to plastic inside the engine compartment.

Last Updated 2/7/2012